



# Corrigo ventilation communication guide

Contains the most commonly used variables. From version 3.3.



© Copyright AB Regin, Sweden, 2013



 **REGIN**

#### THE CHALLENGER IN BUILDING AUTOMATION

## **DISCLAIMER**

The information in this manual has been carefully checked and is believed to be correct. Regin however, makes no warranties as regards the contents of this manual and users are requested to report errors, discrepancies or ambiguities to Regin, so that corrections may be made in future editions. The information in this document is subject to change without prior notification.

The software described in this document is supplied under licence by Regin and may be used or copied only in accordance with the terms of the licence. No part of this document may be reproduced or transmitted in any form, in any fashion, electronically or mechanically, without the express, written permission of Regin.

## **COPYRIGHT**

© AB Regin. All rights reserved.

## **TRADEMARKS**

Corrido, E tool®, EXOdesigner, EXOreal, EXOrealC, EXOline, EXO4, EXO4 Web Server, Optigo, Regio and Regio tool are registered trademarks of AB Regin.

Windows, Windows 2000, Windows XP, Windows 7, Windows 8 and Windows Server 2003 are registered trademarks of Microsoft Corporation.

Some product names mentioned in this document are used for identification purposes only and may be the registered trademarks of their respective companies.

---

Revision 3.3, September 2013

Software revision: 3.3

# Table of contents

<b>CHAPTER 1 INTRODUCTION .....</b>	<b>4</b>
Corrigo ventilation .....	4
About this manual .....	4
Signals .....	4
<b>CHAPTER 2 SIGNAL TYPES AND FUNCTIONS.....</b>	<b>5</b>
Signal types .....	5
<b>CHAPTER 3 COMMONLY USED SIGNALS.....</b>	<b>7</b>
3.1 Input Status.....	7
3.2 Holding Register – Setpoint settings.....	7
3.3 Holding Register – Manual / Auto settings .....	9
3.4 Input Registers.....	11
<b>APPENDIX ALARM LIST .....</b>	<b>14</b>

# Chapter 1 Introduction

---

## Corrigo ventilation

Corrigo ventilation is a pre-programmed application for control of an air handling unit. The Corrigo controller can either be used stand-alone or integrated in an existing EXO project, in both cases it is configured via the display or using the configuration tool E tool<sup>®</sup> on a PC.

## About this manual

This document provides an introduction to communication via Modbus, BACnet and EXOline and contains a list of commonly used signals. This list is found in chapter 3.


A complete list of all signals accessible via Modbus, BACnet and the EXOline protocol is found in the document *Corrigo Ventilation variables* (accessible via the help menu in E tool<sup>®</sup>).

This document does not describe how to create an EXO project or how to set up EXOline communication. For these matters, please refer to the EXO System and E tool<sup>®</sup> manuals.

## Signals

All signals described in this document are accessible from a SCADA/Modbus master system. The signals that have a default value are settings that can be changed; the signals without default values are actual values and cannot be changed.

# Chapter 2 Signal types and functions



## Signal types

All signals accessible from a SCADA system are described further in this document. Signals with a default value are settings that can be changed via a SCADA system. Signals without a default value are actual values which cannot be changed using a SCADA system.

### EXOL type

The EXOL type of signals:

R = Real (-3.3E38 - 3.3E38)

I = Integer (-32768 - 32767)

X = Index (0 - 255)

L = Logic (0/1)

### Modbus type

The Modbus type of signals:

1 = Coil Status Register (Modbus function = 1, 5 and 15)

2 = Input Status Register (Modbus function = 2)

3 = Holding Register (Modbus function = 3, 6 and 16)

4 = Input Register (Modbus function = 4)

Supported Modbus functions:

- 1 = Read Coils
- 2 = Read Discrete Input
- 3 = Read Holding Register
- 4 = Read Input Register
- 5 = Write Single Coil
- 6 = Write Single Register
- 15 = Write Multiple Coils
- 16 = Write Multiple Registers

### **BACnet type**

The BACnet type of signals:

- 10XXX = Read and write binary
- 20XXX = Read binary
- 30XXX = Read and write analogue
- 40XXX = Read analogue
- 30XXX = Read and write multistate
- 40XXX = Read multistate

(Where XXX = Modbus address)

# Chapter 3 Commonly used signals

To simplify system integration, a register of commonly used signals is provided below. Please refer to the document *Corrigo ventilation variables for EXOline, Modbus and BACnet* for a complete list.

## 3.1 Input Status

Signal name	EXOL type	Modbus address	BACnet	Default value	Function	Description
VentActual.Cor_ExtendedRunActi veFull	L	8	BV, 20008		Actual/Setpoint	Set if extended operation full speed
VentActual.Cor_ExtendedRunActi veHalf	L	9	BV, 20009		Actual/Setpoint	Set if extended operation half speed
VentActual.Cor_AlaPt(1) ... VentActual.Cor_AlaPt(48)	L	33 ... 80	BV, 20033 ... BV, 20080		Alarm Points	Run Error Supply Air Fan 0=No alarm 1=Alarm ... Internal battery error
VentActual.Cor_AlaPt(49) ... VentActual.Cor_AlaPt(100)	L	90 ... 141	BV, 20090 ... BV, 20141		Alarm Points	Sensor error Supply Air temp ... Low temp Extra sensor 5

## 3.2 Holding Register – Setpoint settings

Holding register values are adjustable (read/write).

Signal name	EXOL type	Modbus address	BACnet	Default value	Function	Description
VentSettings.Cor_SupplySetpoint	R	1	AV, 30001	18°C	Supply, Extract and Room temperatures	Setpoint supply air temperature when constant supply air temperature function
VentSettings.Cor_ExhaustSetpoint	R	18	AV, 30018	21°C	Supply, Extract and Room temperatures	Setpoint extract air temp if extract air temp control function

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentSettings.Cor_RoomSetP	R	19	AV, 30019	21°C	Supply, Extract and Room temperatures	Room setpoint if room temp control function
VentSettings.Cor_SAFFullspeedPressure	R	24	AV, 30024	500 Pa	SAF/EAF Pressure and Flow	Setpoint full speed supply air fan pressure
VentSettings.Cor_SAFHalfspeedPressure	R	25	AV, 30025	250 Pa	SAF/EAF Pressure and Flow	Setpoint reduced speed supply air fan pressure
VentSettings.Cor_EAFFullspeedPressure	R	26	AV, 30026	500 Pa	SAF/EAF Pressure and Flow	Setpoint full speed extract air fan pressure
VentSettings.Cor_EAFHalfspeedPressure	R	27	AV, 30027	250 Pa	SAF/EAF Pressure and Flow	Setpoint reduced speed extract air fan pressure
VentSettings.Cor_SAFFullspeedAirFlow	R	28	AV, 30028	2000 m3/h	SAF/EAF Pressure and Flow	Setpoint full speed supply air fan flow. Scale factor = 1
VentSettings.Cor_SAFHalfspeedAirFlow	R	29	AV, 30029	1000 m3/h	SAF/EAF Pressure and Flow	Setpoint reduced speed supply air fan flow. Scale factor = 1
VentSettings.Cor_EAFFullspeedAirFlow	R	30	AV, 30030	2000 m3/h	SAF/EAF Pressure and Flow	Setpoint full speed extract air fan flow. Scale factor = 1
VentSettings.Cor_EAFHalfspeedAirFlow	R	31	AV, 30031	1000 m3/h	SAF/EAF Pressure and Flow	Setpoint reduced speed extract air fan flow. Scale factor = 1
VentActual.Cor_Outdoor temp(0)	R	392	AV, 30392		Actual/Setpoint	Outdoor temperature (Can be modified if it's not connected to a physical analogue input).
VentSettings.Cor_SupplySetpointMax	R	404	AV, 30404	30°C	Supply, Extract and Room temperatures	Max limit of supply setpoint when cascade control
VentSettings.Cor_SupplySetpointMin	R	405	AV, 30405	12°C	Supply, Extract and Room temperatures	Min limit of supply setpoint when cascade control
VentSettings.Cor_DemandCO2Value1	R	465	AV, 30465	800	CO2	Activation of demand-controlled ventilation, 1/2-speed
VentSettings.Cor_DemandCO2Value2	R	466	AV, 30466	1000	CO2	Activation of demand-controlled ventilation, 1/1-speed
VentSettings.Cor_DemandCO2Diff	R	467	AV, 30467	160	CO2	Hysteresis for stop of demand controlled ventilation (ppm)

### 3.3 Holding Register – Manual / Auto settings

Signal name	EXOL type	Modbus address	BACnet	Default value	Function	Description
VentSettings.Cor_AirUnitAutoMode	X	368	MSV, 30368	3	Manual/Auto	Running mode air unit: Modbus: 0=Manual off 1=Manual reduced speed 2=Manual normal speed 3=Auto BACnet: 1=Manual off 2=Manual reduced speed 3=Manual normal speed 4=Auto
VentSettings.Cor_SupplyPID_Select	X	369	-	2	Manual/Auto	Supply temp controller mode: 0=Manual off 1=Manual on 2=Auto
VentSettings.Cor_SupplyPID_ManSet	R	370	-	0 %	Manual/Auto	Supply temp controller output if manual on mode
VentSettings.Cor_SAFAutoMode(0)	X	371	-	3	Manual/Auto	Running mode SAF: 0=Off 1=Manual half speed 2=Manual full speed 3=Auto
VentSettings.Cor_EAFAutoMode	X	372	-	3	Manual/Auto	Running mode EAF: 0=Off 1=Manual half speed 2=Manual full speed 3=Auto
VentSettings.Cor_SAFFrequencyAutoMode	X	373	-	3	Manual/Auto	Running mode frequency controlled SAF 0=Manual 1=Man. half speed 2=Man. Fullspeed 3=Auto
VentSettings.Cor_SAFManual	R	374	-	0 %	Manual/Auto	Frequencer controller output SAF if manual mode
VentSettings.Cor_EAFFrequencyAutoMode	X	375	-	3	Manual/Auto	Running mode frequency controlled EAF 0=Manual 1=Man. half speed 2=Man. Fullspeed 3=Auto
VentSettings.Cor_EAFManual	R	376	-	0 %	Manual/Auto	Frequencer controller output EAF if manual mode

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentSettings.Cor_HeatCoilAutoMode(0)	X	377	-	2	Manual/Auto	Running mode Heating: 0=Off 1=Manual 2=Auto
VentSettings.Cor_HeatCoilManual(0)	R	378	-	0	Manual/Auto	Heating controller output if manual mode
VentSettings.Cor_ExchCoilAutoMode	X	379	-	2	Manual/Auto	Running mode Exchanger: 0=Off 1=Manual 2=Auto
VentSettings.Cor_ExchCoilManual	R	380	-	0	Manual/Auto	Exchanger controller output if manual mode
VentSettings.Cor_CoolCoilAutoMode	X	381	-	2	Manual/Auto	Running mode Cooling: 0=Off 1=Manual 2=Auto
VentSettings.Cor_CoolCoilManual	R	382	-	0	Manual/Auto	Cooling controller output if manual mode
VentSettings.Cor_HumidityPID_Select	X	383	-	2	Manual/Auto	Running mode Humidification/Dehumidification: 0=Off 1=Manual 2=Auto
VentSettings.Cor_HumidityPID_ManSet	R	384	-	0	Manual/Auto	Humidification/Dehumidification controller output if manual mode
VentSettings.Cor_HeatPumpAutoMode(0)	X	385	-	2	Manual/Auto	Running mode P1-Heating: 0=Manual off 1=Manual on 2=Auto
VentSettings.Cor_ExchPumpAutoMode	X	386	-	2	Manual/Auto	Running mode P1-Exchanger: 0=Manual off 1=Manual on 2=Auto
VentSettings.Cor_CoolPumpAutoMode	X	387	-	2	Manual/Auto	Running mode P1-Cooling: 0=Manual off 1=Manual on 2=Auto
VentSettings.Cor_FireDamperAutoMode	X	388	-	2	Manual/Auto	Running mode fire damper: 0=Close 1=Open 2=Auto

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentSettings.Cor_E_xternalControl	X	451	MSV, 30451	2	Manual/Auto	External control:  Modbus: 0=Extended run full speed 1=External stop 2>No external control 3=External stop with support control  BACnet: 1=Extended run full speed 2=External stop 3>No external control 4=External stop with support control

### 3.4 Input Registers

Input register values are read-only.

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentActual.Cor_Ou_tdoor temp(0)	R	1	AV, 40001		Actual/Setpoint	Outdoor temperature (read-only)
VentActual.Cor_Ef_ficiency	R	2	AV, 40002		Actual/Setpoint	Efficiency in % for exchanger

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentActual.Cor_RunMode	X	3	MSV, 40003		Actual/Setpoint	Modbus: 0=Stopped 1=Starting up 2=Starting reduced speed 3=Starting full speed 4=Starting normal run 5=Normal run 6=Support control heating 7=Support control cooling 8=CO2 run 9=Night cooling 10=Full speed stop 11=Stopping fan  BACnet: 1=Stopped 2=Starting up 3=Starting reduced speed 4=Starting full speed 5=Starting normal run 6=Normal run 7=Support control heating 8=Support control cooling 9=CO2 run 10=Night cooling 11=Full speed stop 12=Stopping fan
VentActual.Cor_SupplyAirTemp	R	7	AV, 40007		Supply, Extract and Room temperatures	Supply air temperature
VentActual.Cor_ExtractAirTemp	R	9	AV, 40009		Supply, Extract and Room temperatures	Extract air temp
VentActual.Cor_RoomTemp1	R	10	AV, 40010		Supply, Extract and Room temperatures	Room temperature 1
VentActual.Cor_RoomTemp2	R	11	AV, 40011		Supply, Extract and Room temperatures	Room temperature 2
VentActual.Cor_SAFPressure	R	13	AV, 40013		SAF/EAF Pressure and Flow	Supply air fan pressure (Pa)
VentActual.Cor_EAFPressure	R	14	AV, 40014		SAF/EAF Pressure and Flow	Extract air fan pressure (Pa)
VentActual.Cor_SAAirFlow	R	15	AV, 40015		SAF/EAF Pressure and Flow	Supply air fan flow (m <sup>3</sup> /h). Scale factor = 1
VentActual.Cor_EAAirFlow	R	16	AV, 40016		SAF/EAF Pressure and Flow	Extract air fan flow (m <sup>3</sup> /h). Scale factor = 1

<b>Signal name</b>	<b>EXOL type</b>	<b>Modbus address</b>	<b>BACnet</b>	<b>Default value</b>	<b>Function</b>	<b>Description</b>
VentActual.Cor_C_O2Sensor	R	17	AV, 40017		CO2	CO2 (ppm)
VentActual.Cor_FrostprotectionTemp	R	19	AV, 40019		Frost protection	Frost protection temp
VentActual.Cor_DeIcingTemp	R	21	AV, 40021		Extract air temp/De-icing exchanger	De-icing temp exchanger
VentActual.Cor_HumidityRoom	R	23	AV, 40023		Humidity	Humidity room
VentActual.Cor_ExtraSensor	R	25	AV, 40025		Additional sensor/External setpoint	Extra sensor 1/External setpoint (depending on configuration)
VentActual.Cor_HeatCV1(0)	R	119	AV, 40119		Analogue outputs	Control signal heating Y1 (0...10 V)
VentActual.Cor_ExchCV1	R	120	AV, 40120		Analogue outputs	Control signal exchanger Y2 (0...10 V)
VentActual.Cor_CoolCV1	R	121	AV, 40121		Analogue outputs	Control signal cooler Y3 (0...10 V)
VentActual.Cor_SAF	R	122	AV, 40122		SAF/EAF Pressure and Flow	Control signal supply air fan (0...10 V)
VentActual.Cor_EAF	R	123	AV, 40123		SAF/EAF Pressure and Flow	Control signal extract air fan (0...10 V)
VentActual.Cor_UnitRunMode	X	284	MSV, 40284		Actual/Setpoint	Unit run mode: Modbus: 0=Off 1=Reduced speed 2=Normal speed 3=Stop because of alarm BACnet: 1=Off 2=Reduced speed 3=Normal speed 4=Stop because of alarm
VentActual.Cor_FilterGuard1AI	R	301	AV, 40301		Actual/Setpoint	Analogue filter 1 value (Pa)
VentActual.Cor_FilterGuard2AI	R	302	AV, 40302		Actual/Setpoint	Analogue filter 2 value (Pa)

# Appendix Alarm list

---

No.	Alarm text	Prio	Description
1	Run Error Supply Air Fan	B	Malfunction Supply air fan
2	Run Error Extract Air Fan	B	Malfunction Extract air fan
3	Run Error P1-Heater	B	Malfunction pump, Heating circuit
4	Run Error P1-Cooler	B	Malfunction pump, Cooling circuit
5	Run Error P1-Exchanger	B	Malfunction pump, Liquid connected exchanger
6	Filter guard	B	Filter guard pressure switch activated
7	Flow guard	B	Flow guard activated
8	External frost guard	A	External Frost protection thermostat activated
9	Deicing pressure guard	-	Exchanger de-icing pressure switch activated
10	Fire alarm	A	Fire alarm activated
11	External switch	C	External switch activated
12	External alarm	B	External alarm activated
13	Supply Air control error	B	Supply air temp deviates too much from the setpoint for too long
14	Humidity control error	-	The room humidity deviates too much from the setpoint.
15	High supply air temp	B	Supply air temp too high
16	Low supply air temp	B	Supply air temp too low
17	Supply air temp max	-	Maximum limiting of supply air temp active
18	Supply air temp min	-	Minimum limiting of supply air temp active
19	High room temp	B	Room temp too high during room temp control
20	Low room temp	B	Room temp too low during room temp control
21	High extract air temp	B	High extract air temp during extract air control
22	Low extract air temp	B	Low extract air temp during extract air control
23	Electric heating is overheated	A	Heater high temperature limit switch activated
24	Frost risk	B	Frost protection function is overriding the control of the heater output
25	Low frostguard temp	A	Frost protection temperature below frost limit value
26	Low efficiency	B	Heat exchanger efficiency below limit value
27	Sensor error Outdoor temp	B	Malfunction of connected sensor
28	Analogue deicing	-	Exchanger de-icing activated by de-icing sensor
29	Rotation guard exchanger	B	Exchanger rotation sentinel alarm activated
30	Fire damper is out of operation	B	Fire damper exercise test failed
31	Supply Air Fan control error	-	Supply air pressure deviates too much from the setpoint for too long
32	Extract Air Fan control error	-	Extract air pressure deviates too much from the setpoint for too long
33	Supply Air Fan external operation	C	SAF run-signal received when unit is stopped
34	Extract Air Fan external operation	C	EAF run-signal received when unit is stopped
35	Ventilation Manual mode	C	The unit is shut down
36	Manual supply air control	C	Supply air temp controller in manual control
37	Manual supply Air Fan mode	C	Supply air fan in manual control
38	Freq. SAF Manual	C	Signal to SAF frequency converter in manual control

No.	Alarm text	Prio	Description
39	Manual Extract Air Fan mode	C	Extract air fan in manual control
40	Freq. EAF Manual	C	Signal to SAF frequency converter in manual control
41	Heating Manual Manual	C	Heating output in manual control
42	Manual exchanger control	C	Heat exchanger output in manual control
43	Manual cooler control	C	Cooling output in manual control
44	Manual P1-Heater	C	Heating circulation pump in manual control
45	Manual P1-Exchanger	C	Exchanger circulation pump in manual control
46	Manual P1-Cooler	C	Cooling circulation pump in manual control
47	Fire damp. Manual	C	Fire dampers in manual control
48	Internal battery error	A	Internal battery needs replacing
49	Sensor error Supply Air temp	B	Malfunction of connected sensor
50	Sensor error Extract Air temp	B	Malfunction of connected sensor
51	Sensor error Room temp 1	B	Malfunction of connected sensor
52	Sensor error Room temp 2	B	Malfunction of connected sensor
53	Sensor error Exhaust air temp	B	Malfunction of connected sensor
54	Sensor error Extra sensor	B	Malfunction of connected sensor
55	Sensor error SAF pressure	B	Malfunction of connected sensor
56	Sensor error EAF pressure	B	Malfunction of connected sensor
57	Sensor error Deicing temp	B	Malfunction of connected sensor
58	Sensor error Frost Protection temp	B	Malfunction of connected sensor
59	Sensor error CO2	B	Malfunction of connected sensor
60	Sensor error Humidity Room	B	Malfunction of connected sensor
61	Sensor error Humidity Duct	B	Malfunction of connected sensor
62	Sensor error Extra unit temp	B	Malfunction of connected sensor
63	Sensor error External control SAF	B	Malfunction of connected sensor
64	Sensor error External control EAF	B	Malfunction of connected sensor
65	Sensor error SAF Pressure 2	B	Malfunction of connected sensor
66	Sensor error Humidity outdoor	B	Malfunction of connected sensor
77	Alarm Frequency converter SAF	A	Malfunction of frequency converter SAF
78	Alarm Frequency converter EAF	A	Malfunction of frequency converter EAF
79	Communication error Frequency SAF	C	Communication problem with Vacon NXL
80	Communication error Frequency EAF	C	Communication problem with Vacon NXL
81	Communication error Expansion unit 1	C	Communication problem with a controller connected to port 2
82	Communication error Expansion unit 2	C	Communication problem with a controller connected to port 2
83	Warning Frequency converter SAF	C	
84	Warning Frequency converter EAF	C	
85	Output in manual mode	C	Analogue or digital output in manual mode
86	Time for service	C	Time for service
87	Manual Y4-Extra Sequence control	C	Y4-Extra sequence in manual control
88	Restart blocked after power failure	C	Restart blocked after power failure
89	Manual Y5-Extra Sequence control	C	Y5-Extra sequence in manual control
90	Filter guard 2	B	Filter guard pressure switch activated
91	High temp Extra sensor 1	-	High temperature Extra sensor 1
92	Low temp Extra sensor 1	-	Low temperature Extra sensor 1

No.	Alarm text	Prio	Description
93	High temp Extra sensor 2	-	High temperature Extra sensor 2
94	Low temp Extra sensor 2	-	Low temperature Extra sensor 2
95	High temp Extra sensor 3	-	High temperature Extra sensor 3
96	Low temp Extra sensor 3	-	Low temperature Extra sensor 3
97	High temp Extra sensor 4	-	High temperature Extra sensor 4
98	Low temp Extra sensor 4	-	Low temperature Extra sensor 4
99	High temp Extra sensor 5	-	High temperature Extra sensor 5
100	Low temp Extra sensor 5	-	Low temperature Extra sensor 5

REGIN - THE CHALLENGER IN BUILDING AUTOMATION

## AB Regin

### Head office

Box 116, S-428 22 Källered,  
Sweden

Phone: +46 31 720 02 00      [info@regin.se](mailto:info@regin.se)  
Fax: +46 31 720 02 50      [www.regin.se](http://www.regin.se)

