

'MAXI' PEDESTAL TYPE VIBRATION & SHOCK ISOLATORS

TYPE: MPO & MP1

INSTALLATION INSTRUCTIONS

In order to ensure the correct installation of the above type of mountings, please adhere to the following procedure:

1. Position the Anti-Vibration Mountings beneath the base of the equipment to be isolated, with fixing screw removed.
2. Line up the holes in the base of the equipment to be isolated with the tapped holes in the Anti-Vibration Mountings.
3. Lower the equipment on to the Anti-Vibration Mountings.
4. Wind the fixing lock nut down the fixing set screw.
5. Position the washer over the equipment fixing hole and insert the fixing set screw/lock nut assembly.
6. Wind the fixing set screw into the Anti-Vibration Mounting and secure into position using the lock nut.
7. This range of mountings has provision for bolting to the floor or supporting structure.
8. Further adjustment and maintenance are not required.

This mounting should not be used in either tension or shear - to be used in compression only.

