

[illegible]

KW	Vorsicherung	Zuleitung -W1	Entrauchungsventilator -W2 -W3	
4	T 20 A	* 5x2,5 qmm	* 4x2,5 qmm	* 4x2,5 qmm
5,5	T 25 A	* 5x4 qmm	* 4x4 qmm	* 4x4 qmm
7,5	T 25 A	* 5x4 qmm	* 4x4 qmm	* 4x4 qmm
11	T 35 A	* 5x6 qmm	* 4x6 qmm	* 4x6 qmm
15	T 50 A	* 5x10 qmm	* 4x10 qmm	* 4x10 qmm
18,5	T 63 A	* 5x16 qmm	* 4x16 qmm	* 4x16 qmm
22	T 80 A	* 5x25 qmm	* 4x25 qmm	* 4x25 qmm
30	T 100 A	* 5x35 qmm	* 4x35 qmm	* 4x35 qmm
45	T 125 A	* 5x50 qmm	* 4x50 qmm	* 4x50 qmm

The connection of the auxiliary contacts of F1 and the cables L01, unit 1, N see data sheet AES-ST3.2

The current value of the motor protection relay has to be set before placing in operation.