

1. First install the filter on the valve, ensure that the filter surrounds the valve and the rubber seal all around.
2. Then press the filter and the valve in the valve tube.
3. If you have mounted correctly, the rubber seal will keep the valve in the pipe in the correct position without the need to screw the valve.

